110 electrical plug wiring

110 electrical plug wiring is a fundamental aspect of residential and commercial electrical systems in North America. Understanding how to properly wire a 110-volt plug is essential for ensuring safety, functionality, and compliance with electrical codes. This article provides a comprehensive overview of 110 electrical plug wiring, including the types of plugs, wiring components, step-by-step wiring instructions, and safety considerations. Additionally, it covers troubleshooting tips and common mistakes to avoid when working with 110-volt electrical plugs. Whether you are an electrician, technician, or DIY enthusiast, this guide aims to equip you with the knowledge necessary to handle 110 electrical plug wiring confidently and correctly. The detailed explanations and practical advice included here will help maintain the integrity and reliability of your electrical connections.

- Understanding 110 Electrical Plug Wiring
- Components of a 110 Electrical Plug
- Step-by-Step Guide to Wiring a 110 Electrical Plug
- Safety Precautions and Best Practices
- Troubleshooting Common Wiring Issues

Understanding 110 Electrical Plug Wiring

110 electrical plug wiring involves connecting electrical cords and outlets designed to operate at 110 volts, the standard voltage for most household and light commercial applications in the United States and Canada. This wiring process ensures that appliances and devices receive power safely and efficiently. The 110-volt system typically uses a single hot wire, a neutral wire, and a ground wire to complete the circuit. Proper wiring is critical to prevent electrical hazards, such as shocks, short circuits, or fires. Familiarity with the wiring configuration and color codes is essential for anyone working with these plugs to guarantee correct installation and functionality.

Voltage and Current Specifications

The 110 electrical plug is designed for circuits operating at approximately 110 to 120 volts alternating current (AC). The standard amperage rating for typical household plugs is 15 or 20 amps, depending on the circuit design and the type of plug used. Understanding these electrical specifications helps in selecting the appropriate plug and wire gauge for the intended application.

Common Applications

110 electrical plugs are predominantly used for powering household appliances, lighting fixtures, power tools, and electronic devices. Their widespread use necessitates strict adherence to wiring standards to ensure compatibility and safety across various electrical systems.

Components of a 110 Electrical Plug

A 110 electrical plug consists of several key components that work together to provide a secure and reliable electrical connection. Each component plays a specific role in the overall wiring setup and must be handled with care during installation.

Plug Housing

The plug housing is the outer shell that encases and protects the internal wiring and contacts. It is typically made from durable, non-conductive materials such as plastic or rubber to prevent electrical shock and physical damage.

Electrical Contacts

Inside the plug housing are the electrical contacts or prongs. For a 110 plug, there are usually two flat prongs—one hot (live) and one neutral—and a round or U-shaped grounding prong. These contacts establish the electrical connection between the plug and the outlet.

Wiring Terminals

Wiring terminals are the points where the electrical wires are connected to the plug’s contacts. They are designed to secure the wires firmly, ensuring a stable electrical path. Proper attachment of the wires to the terminals is critical for safe and effective plug operation.

Wire Types and Color Coding

Standard wire colors used in 110 electrical plug wiring are black for hot, white for neutral, and green or bare copper for ground. This color coding helps in identifying the wires during installation and maintenance, reducing wiring errors.

Step-by-Step Guide to Wiring a 110 Electrical Plug

Wiring a 110 electrical plug requires careful attention to detail and adherence to electrical standards. The following step-by-step instructions outline the correct procedure to ensure a safe and functional wiring connection.

1. **Turn Off Power:** Before beginning any wiring work, ensure that the power supply to the circuit is turned off at the breaker panel to prevent electrical shock.

2. **Prepare the Cable:** Strip the outer insulation of the electrical cable to expose the individual wires (hot, neutral, and ground) without damaging the wire strands.

3. **Strip Wire Ends:** Remove about 3/4 inch of insulation from each wire end to prepare for connection to the plug terminals.

4. **Identify Wire Colors:** Confirm that the black wire is hot, the white wire is neutral, and the green or bare wire is ground.

5. **Connect the Wires:** Attach the black (hot) wire to the brass or gold-colored terminal, the white (neutral) wire to the silver-colored terminal, and the green or bare ground wire to the green grounding terminal.

6. **Tighten Terminal Screws:** Secure the wires under the terminal screws, ensuring there is no loose connection or exposed wire beyond the terminal.

7. **Assemble the Plug Housing:** Carefully place the wired terminals into the plug housing and fasten the housing screws to secure the assembly.

8. **Inspect the Connection:** Double-check all connections for tightness and proper placement before restoring power.

9. **Test the Plug:** Once reassembled and the power is restored, test the plug with a voltage tester or a compatible device to verify proper wiring.

Safety Precautions and Best Practices

Safety is paramount when working with 110 electrical plug wiring. Proper precautions and adherence to best practices can prevent accidents and ensure long-term reliability of electrical installations.

Use Appropriate Tools and Equipment

Always use insulated tools designed for electrical work to minimize the risk of shock. Ensure that wire strippers, screwdrivers, and voltage testers are in good condition and rated for the voltage level.

Follow Electrical Codes and Standards

Compliance with the National Electrical Code (NEC) and local regulations is mandatory. These codes specify correct wiring methods, materials, and safety requirements for 110 electrical plug wiring.

Verify Power is Off

Before handling any wiring, verify that the circuit breaker is off and use a voltage tester to confirm the absence of electrical current.

Maintain Wire Integrity

Avoid nicking or damaging wire strands when stripping insulation. Damaged wires can cause poor connections and increase the risk of overheating or electrical faults.

Secure Connections

Ensure all terminal screws are tightly secured and that wires are properly seated in their terminals. Loose connections can lead to arcing and fire hazards.

- Wear appropriate personal protective equipment (PPE) such as gloves and safety glasses.
- Do not overload circuits; adhere to specified amperage limits.
- Use plugs and cords that are rated for the intended electrical load.
- Replace damaged or worn plugs immediately.

Troubleshooting Common Wiring Issues

Even with careful installation, issues can arise with 110 electrical plug wiring. Identifying and resolving these problems promptly helps maintain electrical safety and device performance.

Loose Connections

Loose wire connections can cause intermittent power loss or sparking. If a plug is overheating or devices connected to it malfunction, inspect and tighten the terminal screws.

Incorrect Wiring

Reversed hot and neutral wires can create shock hazards and damage sensitive equipment. Use a circuit tester to verify correct polarity and rewire if necessary.

Damaged Wire Insulation

Exposed or damaged insulation increases the risk of short circuits and electrical shocks. Inspect wires for cuts or abrasions and replace any damaged sections.

Grounding Issues

A missing or improperly connected ground wire can compromise safety. Confirm that the ground wire is securely connected to the grounding terminal and the outlet’s grounding system.

Plug Not Fitting Properly

If the plug does not fit snugly into the outlet, it can cause poor contact and arcing. Check for damage to the plug prongs or outlet and replace as needed.

Frequently Asked Questions

What is a 110 electrical plug wiring?

110 electrical plug wiring refers to the wiring configuration used for plugs designed to connect to 110-volt electrical outlets, commonly found in North America for standard household appliances.

How do I wire a 110 electrical plug correctly?

To wire a 110 electrical plug, connect the black (hot) wire to the brass terminal, the white (neutral) wire to the silver terminal, and the green or bare copper (ground) wire to the green grounding terminal.

What colors correspond to which wires in 110 electrical plug wiring?

In 110 electrical wiring, the black wire is hot (live), the white wire is neutral, and the green or bare copper wire is ground.

Can I use a 110 electrical plug for a 220-volt appliance?

No, a 110 electrical plug is designed for 110-volt circuits and should not be used for 220-volt appliances as it can cause damage or pose safety hazards.

What tools do I need to wire a 110 electrical plug?

You will need a screwdriver, wire stripper, voltage tester, and possibly pliers to properly wire a 110 electrical plug.

Is it safe to wire a 110 electrical plug myself?

If you have basic electrical knowledge and follow safety guidelines, wiring a 110 electrical plug yourself can be safe. However, if unsure, it's best to consult a licensed electrician.

How do I test a 110 electrical plug after wiring it?

Use a voltage tester or plug tester to ensure the plug is wired correctly and the circuit is live and grounded properly after wiring a 110 electrical plug.

What standards govern 110 electrical plug wiring?

In the US and Canada, the National Electrical Code (NEC) and Canadian Electrical Code (CEC) set standards for wiring 110 electrical plugs and outlets.

Can I replace a damaged 110 electrical plug by rewiring it?

Yes, you can replace a damaged 110 electrical plug by cutting off the old plug and wiring a new one following correct wiring color codes and safety precautions.

What common mistakes should I avoid when wiring a 110 electrical plug?

Common mistakes include reversing hot and neutral wires, neglecting the ground wire, using incorrect wire gauge, and not securing the wires tightly to terminals.

Additional Resources

1. *Understanding 110 Electrical Plug Wiring: A Beginner's Guide*
This book serves as an introductory manual for anyone new to electrical wiring, focusing specifically on 110-volt plug configurations. It covers the basics of electrical circuits, safety protocols, and step-by-step instructions for wiring standard 110 plugs. The clear illustrations and simple language make it ideal for DIY enthusiasts and students.

2. *Practical Wiring Techniques for 110-Volt Electrical Systems*
Designed for both novices and intermediate electricians, this book delves into practical methods for wiring 110-volt plugs and outlets. It includes troubleshooting tips, common mistakes to avoid, and detailed explanations of wiring color codes. Readers will gain confidence in handling residential and light commercial electrical projects.

3. *The Complete Guide to Residential 110 Plug Wiring*
This comprehensive guide covers everything from selecting the right materials to installing and testing 110-volt plugs in residential settings. It highlights national electrical codes and emphasizes safety standards. Perfect for homeowners and professionals seeking an in-depth resource on household electrical wiring.

4. *Electrical Plug Wiring Made Easy: Focus on 110-Volt Systems*
With a focus on simplification, this book breaks down complex wiring concepts into manageable

steps, concentrating on 110-volt plug setups. It features diagrams, tool recommendations, and maintenance advice. The user-friendly approach helps readers avoid hazards and ensures efficient wiring outcomes.

5. *Wiring 110-Volt Electrical Plugs: Troubleshooting and Repairs*
This book is a valuable resource for diagnosing and fixing common issues related to 110-volt plug wiring. It guides readers through identifying faulty connections, replacing damaged components, and ensuring compliance with electrical standards. Ideal for electricians and DIYers aiming to maintain safe and reliable wiring.

6. *Safe and Efficient Wiring of 110 Electrical Plugs*
Focusing on safety and efficiency, this title explores best practices for wiring 110-volt plugs in various environments. It discusses grounding techniques, circuit protection, and energy-saving tips. The book is a must-read for those who prioritize safety while enhancing electrical system performance.

7. *Residential Electrical Wiring: Mastering the 110-Volt Plug*
Aimed at homeowners and apprentices, this book teaches the fundamentals of 110-volt plug wiring within the home. It includes project plans, code compliance checklists, and expert advice on installation techniques. Readers will develop the skills needed to confidently handle everyday electrical tasks.

8. *110-Volt Electrical Plug Wiring for HVAC and Appliances*
This specialized book addresses wiring 110-volt plugs for heating, ventilation, air conditioning, and household appliances. It covers unique wiring requirements, safety considerations, and troubleshooting specific to appliance installations. Professionals and DIYers working with home appliances will find this guide invaluable.

9. *Advanced 110 Electrical Plug Wiring and Circuit Design*
Targeted at experienced electricians and engineers, this book explores advanced concepts in wiring 110-volt plugs and designing related circuits. It includes complex schematics, load calculations, and integration with smart home systems. The book is ideal for those seeking to deepen their technical expertise in residential electrical wiring.

110 Electrical Plug Wiring

Find other PDF articles:
https://admin.nordenson.com/archive-library-504/Book?dataid=oqQ29-3184&title=mc-guire-child-development-center-west-monroe-photos.pdf

110 electrical plug wiring: TM 9-2350-255-20-1-3-6 TANK, COMBAT, FULL TRACKED 105-MM GUN, M1 GENERAL ABRAMS Organizational Maintenance Manual Volume III Part 6 of 6 Hull U.S. Army, 1982-12-31 I scanned the original manual at 600 dpi.

110 electrical plug wiring: List of Inspected Electrical Appliances , 1928

110 electrical plug wiring: Organizational Maintenance Repair Parts and Special Tools List for Launcher and M48A5 Tank Chassis, Transporting, for Bridge,

Armored-vehicle-launched, Scissoring Type, Class 60, (5420-01-076-6096). , 1987

110 electrical plug wiring: Radon Reduction Techniques for Existing Detached Houses D. Bruce Henchel, 1993

110 electrical plug wiring: Technical Manual United States Department of the Army,

110 electrical plug wiring: Organizational Maintenance Repair Parts and Special Tools List for Tank, Combat, Full-tracked, 105-mm Gun, M60A1 (2350-00-756-8497) and 105-mm Gun, M60A1 (AOS) (2350-01-058-9487) Hull , 1987

110 electrical plug wiring: 1926-1929 National Board of Fire Underwriters, 1926

110 electrical plug wiring: ,

110 electrical plug wiring: *Manuals Combined: Over 40 U.S. Army M35 M35A2 M35A3 M49 M49A1 M49A2 M44 M44A1 Repair Parts, Maintenance And Operator Manuals* , Over 17,200 total pages ... Just a sample of the contents: Parts Technical Manuals 9-2320-386-24P parts manual M35A3 9-2320-204-34P Parts manual LDS 427 engine 9-2320-209-20P Parts manual organizational level 9-2320-209-34P Parts manual Direct and general support 9-2815-210-34 Engine parts manual Mutilfuel engine 9-2320-361-20P Parts manual organizational level 9-2320-361-34P Parts manual Direct and general support Repair Technical Manuals - Organizational Level 9-2320-209-20-2-1 Volume 2 of 3 part 1 of 2 troubleshooting organizational level 9-2320-209-20-2-2 Volume 3 of 3 part 2 of 2 troubleshooting organizational level 9-2320-209-20-3-1 Organizational level maintenance manual 9-2320-209-20-3-2 Organizational level maintenance manual 9-2320-209-20-3-3 Organizational level maintenance manual 9-2320-209-20-3-4 Organizational level maintenance manual 9-2320-209-20-1 Scheduled maintenance organizational level 9-2320-361-20 Organizational level maintenance manual Transmission & Transfer Technical Manuals 9-2520-246-34-1 9-2520-246-34P 9-2520-246-34 Operator Technical Manuals 9-2320-361-10 M35 series operators manual 9-2320-209-10-1 operation, scheduled maintenance 9-2320-209-10-1HR Hand receipt manual (BII) 9-2320-209-10-2 Scheduled maintenance 9-2320-209-10-3 Operator troubleshooting 9-2320-209-10-4 Operator maintenance 9-2320-386-10 M35A3 operators manual Repair Technical Manuals - Direct & General Support 9-2320-209-34-1 Troubleshooting Direct & General support maintenance level 9-2320-209-34-2-2 Direct & General support maintenance level 9-2320-209-34-2-3 Direct & General support maintenance level 9-2320-361-34 Direct & General support maintenance level (newer updated manual) 9-2320-386-24-1-1 M35A3 manual 9-2320-386-24-1-1 M35A3 manual Engine Technical Manuals 9-2815-210-34-1 Troubleshooting manual for the LDS 465 mutilfuel engine 9-2815-210-34-2-1 Engine assembly manual LDS 465 mutilfuel engine part 1 of 2 9-2815-210-34-2-2 Engine assembly manual LDS 465 mutilfuel engine part 2 of 2 9-2815-204-35 Engine repair manual for the LDS-427-2 mutilfuel engine 9-2815-226-34 Pump fuel metering, mutilfuel engines (all)

110 electrical plug wiring: Royce's Powerboating Illustrated Workbook Patrick M. Royce, 1994

110 electrical plug wiring: *Manuals Combined: U.S. Army M809 M110 M112 M113 6X6 5-Ton Diesel Truck Operator Repair Parts Manuals* , Over 5,100 total pages .... CONTENTS: Operator Manual - 414 pages - June 14, 1985 - w/Changes 1-4TM 9-2320-260-10TO 36A12-1C-481 Unit Repair Manual - 1339 pages - April 1, 1995TM 9-2320-260-20TO 36A12-1C-491Depot Repair Manual Vol 1 - 653 pages - July 1, 1994TM 9-2320-260-34-1TO 36A12-1C-1122-1Depot Repair Manual Vol 2 - 865 pages - June 1, 1994TM 9-2320-260-34-2TO 36A12-1C-1122-2Parts List Vol 1 - 696 pages - September 1, 2003TM 9-2320-260-24P-1TO 36A12-1C-382-1Parts List Vol 2 - 1020 pages - September 1, 2003TM 9-2320-260-24P-2TO 36A12-1C-382-2 Hand Receipt - 20 pages - January 31, 1979TM 9-2320-260-10-HRLubrication Order - 35 pages - November 4, 1983TM 9-2320-260-12Transportability Guidance - 78 pages - July 17, 1986 - w/Change 1TM 55-2320-260-15-1 These manuals cover the following vehicles: M809 Series Trucks, Diesel, 5-Ton, 6x6M810 Truck, Chassis (2320-00-051-0586 & 2320-00-051-0585)M812A1 Truck, Chassis, Rocket Launcher (2320-00-050-9040)M813 Truck, Cargo (2320-00-050-8902 & 2320-00-050-8890)M813A1 Truck, Cargo (2320-00-050-8913 & 2320-00-050-8905)M814 Truck, Cargo (2320-00-050-8988 &

2320-00-050-8987)M815 Truck, Bolster, Logging (2320-00-050-8927)M816 Truck, Wrecker, Medium (2320-00-051-0489)M817 Truck, Dump (2320-00-050-8970 & 2320-00-051-0589)M818 Truck, Tractor (2320-00-050-8984 & 2320-00-050-8978) M819 Truck, Tractor, Wrecker (2320-00-050-9004)M820 Truck, Van, Expansible (2320-00-050-9006)M820A1 Truck, Van, Expansible (2320-00-050-9007)M820A2 Truck, Van, Expansible (2320-00-050-9010)M821 Truck, Stake, Bridge Transporting (2320-00-050-9015)NHC-250 Cummins 6 Cylinder Diesel Engine

110 electrical plug wiring: Index of Specifications and Standards , 2005

110 electrical plug wiring: Department Of Defense Index of Specifications and Standards Federal Supply Class Listing (FSC) Part III September 2005 ,

110 electrical plug wiring: Electrical Installation Record , 1929

110 electrical plug wiring: *New York Review of the Telegraph and Telephone and Electrical Journal* , 1912

110 electrical plug wiring: Official Gazette of the United States Patent and Trademark Office , 2002

110 electrical plug wiring: *Electrical Review* , 1917

110 electrical plug wiring: Electrical Review and Western Electrician with which is Consolidated Electrocraft , 1916

110 electrical plug wiring: Electrical Merchandising Week , 1920 Includes annually, 1961- Home goods data book.

110 electrical plug wiring: Organizational, Direct Support, and General Support Maintenance Repair Parts and Special Tools Lists (including Depot Maintenance Allowances) for Hull, Suspension, and Miscellaneous Components of Hull for Armored Reconnaissance/airborne Assault Vehicle, Full Tracked, 152 Mm, M551 (2350-00-873-5408) and M551A1 (2350-00-140-5151). , 1981

Related to 110 electrical plug wiring

□□□□□□□□110□□□□□□□□□□□ - □□ □□□□□□□□□ 110□□ □□□□□□□□ □□□110□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □ □□□□□ □□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□**2025**□□□□□□□□□ 5000□□□□25□□□□□□□□□□□□□□□□ □□F2z 110 Max□Mz 110□□□□□□□Qz1 MIX□□ 6000□□□□□□□□□□□□□□□□MMAX□□□□□□Dz 110P□□□□□□□□□□

□□□□□□□□□110□□□□□□ - □□ □□□ □□□□□□□□□ □□□□□□□□□□□ □□□□□□□□□□□

□□□□□□□□□□□□□110□90□60□50? - □□ 110□□□90□□□60□□□50□□□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□110□□□□□□□□□□□□□□□□□□□ - □□ □□□□□□□□110□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□1

□ftp□□□□□□□□□□□? - □□ □□□□□□□FTP□□□□□□□□□□□□□□□□□□□□□□ 1.□□□□□□□□□□□□□□□□□□□□□□□□□□□□FTP□ 2.□□□□□□□ □Windows□□□□□□□□□□□□□□□□□□□□□□□

□□110□119□120□□□□□□□□□□□□□□□□□□ - □□ □□□□110□□□119□□□□□□120□ □□□□□ □□□□999□□□□□122□□□□□□□□□□□□ □12395□□□□□95110□□□□□□□□□□□□□12308□□□□□□□□□□

□□ 110 □□□□□□□□□□□□□□□□□□□ - □□ □□ 110 □□□□□□□□□□□□□□□□□□□ □□□□□□110□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□ 1□□□□□□□□□□□□□ □□□□□□□□□□□□□□□

□□□□□□□□□□□ - □□ □□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□1□□□70-190 1□11□□□80-160□□□□□128□□ □130□ 1-2□□80-130□□□□□116□□□□□119□ 3

□□□□□□□□110□□□□□□□□□□□ - □□ □□□□□□□□□ 110□□ □□□□□□□□ □□□110□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □ □□□□□ □□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□□**2025**□□□□□□□□□ 5000□□□□25□□□□□□□□□□□□□□□□ □□F2z 110 Max□Mz 110□□□□□□□Qz1 MIX□□ 6000□□□□□□□□□□□□□□□□MMAX□□□□□□Dz 110P□□□□□□□□□□

□□□□□□□□□110□□□□□□ - □□ □□□ □□□□□□□□□

□□□□□□□□□□□ □□□□□□□□□□□

□□□□□□□□□□□110□90□60□50? - □□ 110□□□90□□□60□□□50□□□□□□□□□□□□□□□□ □□

□□□□□□110□□□□□□□□□□□□□□□□□ - □□ □□□□□□110□□□□□□□□□□□□□ □□□1

□ftp□□□□□□□□□□? - □□ □□□□□□FTP□□□□□□□□□□□□□□□□□□□□ 1.□□□□□□□□□□□□□□□□□□□□□□□□□□□□FTP□ 2.□□□□□□□Windows□□□□□□□□□□□□□□□□□□□□□□□

□□110□119□120□□□□□□□□□□□□□□□□ - □□ □□□□110□□□119□□□□□120□ □□□□ □□□□999□□□□□122□□□□□□□□□□□12395□□□□□95110□□□□□□□□□□□□12308□□□□□□□□□

□□ 110 □□□□□□□□□□□□□□□□□□□ - □□ □□ 110 □□□□□□□□□□□□□□□□□□□ □□□□□110□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□1□□□□□□□□□□□□ □□□□□□□□□□□□□□

□□□□□□□□□□□ - □□ □□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□1□□□70-190 1□11□□□80-160□□□□□128□□□130□ 1-2□□80-130□□□□□116□□□□□119□ 3

□□□□□□□110□□□□□□□□□□□ - □□ □□□□□□□□□ 110□□ □□□□□□□ □□□110□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□ □□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□2025□□□□□□□□ 5000□□□□25□□□□□□□□□□□□□□□□ □□F2z 110 Max□Mz 110□□□□□□Qz1 MIX□□6000□□□□□□□□□□□□□□□□MMAX□□□□□□Dz 110P□□□□□□□□□□

□□□□□□□□□110□□□□□ - □□ □□□ □□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□□

□□□□□□□□□□□110□90□60□50? - □□ 110□□□90□□□60□□□50□□□□□□□□□□□□□□□□ □□

□□□□□□110□□□□□□□□□□□□□□□□□ - □□ □□□□□□110□□□□□□□□□□□□□ □□□1

□ftp□□□□□□□□□□? - □□ □□□□□□FTP□□□□□□□□□□□□□□□□□□□□ 1.□□□□□□□□□□□□□□□□□□□□□□□□□□□□FTP□ 2.□□□□□□□Windows□□□□□□□□□□□□□□□□□□□□□□□

□□110□119□120□□□□□□□□□□□□□□□□ - □□ □□□□110□□□119□□□□□120□ □□□□ □□□□999□□□□□122□□□□□□□□□□□12395□□□□□95110□□□□□□□□□□□□12308□□□□□□□□□

□□ 110 □□□□□□□□□□□□□□□□□□□ - □□ □□ 110 □□□□□□□□□□□□□□□□□□□ □□□□□110□□□

□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□1□□□□□□□□□□□□ □□□□□□□□□□□□□□

□□□□□□□□□□□ - □□ □□□□□□□ □□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□1□□□70-190 1□11□□□80-160□□□□□128□□□130□ 1-2□□80-130□□□□□116□□□□□119□ 3

□□□□□□□110□□□□□□□□□□□ - □□ □□□□□□□□□ 110□□ □□□□□□□ □□□110□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□ □□□□□□□□□□□□□□□□□□□□□

□□□□□□□□□□□□□□2025□□□□□□□□ 5000□□□□25□□□□□□□□□□□□□□□□ □□F2z 110 Max□Mz 110□□□□□□Qz1 MIX□□6000□□□□□□□□□□□□□□□□MMAX□□□□□□Dz 110P□□□□□□□□□□

□□□□□□□□□110□□□□□ - □□ □□□ □□□□□□□□□□□□□□□□□□□□□□□□□ □□□□□□□□□□

□□□□□□□□□□□110□90□60□50? - □□ 110□□□90□□□60□□□50□□□□□□□□□□□□□□□□ □□

□□□□□□110□□□□□□□□□□□□□□□□□ - □□ □□□□□□110□□□□□□□□□□□□□ □□□1

□ftp□□□□□□□□□□? - □□ □□□□□□FTP□□□□□□□□□□□□□□□□□□□□ 1.□□□□□□□□□□□□□□□□□□□□□□□□□□□□FTP□ 2.□□□□□□□Windows□□□□□□□□□□□□□□□□□□□□□□□

□□110□119□120□□□□□□□□□□□□□□□□ - □□ □□□□110□□□119□□□□□120□ □□□□ □□□□999□□□□□122□□□□□□□□□□□12395□□□□□95110□□□□□□□□□□□□12308□□□□□□□□□

□□ 110 □□□□□□□□□□□□□□□□□□□ - □□ □□ 110 □□□□□□□□□□□□□□□□□□□ □□□□□110□□□

[illegible] [illegible]
1[illegible] [illegible]

[illegible] **-** [illegible] [illegible] [illegible] [illegible]1[illegible]70-190 1[illegible]11[illegible]80-160[illegible]128[illegible]130[illegible] 1-2[illegible]80-130[illegible]116[illegible]119[illegible] 3

[illegible]**110**[illegible] **-** [illegible] [illegible] 110[illegible] [illegible] [illegible]110[illegible] [illegible] [illegible]

[illegible]**2025**[illegible] 5000[illegible]25[illegible] [illegible]F2z 110 Max[illegible]Mz 110[illegible]Qz1 MIX[illegible]6000[illegible]MMAX[illegible]Dz 110P[illegible]

[illegible]**110**[illegible] **-** [illegible] [illegible] [illegible] [illegible]

[illegible]**110[illegible]90[illegible]60[illegible]50? -** [illegible] 110[illegible]90[illegible]60[illegible]50[illegible] [illegible]

[illegible]**110**[illegible] **-** [illegible] [illegible]110[illegible] [illegible]1

[illegible]**ftp**[illegible]**? -** [illegible] [illegible]FTP[illegible] 1.[illegible]FTP[illegible] 2.[illegible]Windows[illegible]

[illegible]**110[illegible]119[illegible]120**[illegible] **-** [illegible] [illegible]110[illegible]119[illegible]120[illegible] [illegible] [illegible]999[illegible]122[illegible]12395[illegible]95110[illegible]12308[illegible]

[illegible] **110** [illegible] **-** [illegible] 110 [illegible] [illegible]110[illegible]

[illegible] [illegible]
1[illegible] [illegible]

[illegible] **-** [illegible] [illegible] [illegible] [illegible]1[illegible]70-190 1[illegible]11[illegible]80-160[illegible]128[illegible]130[illegible] 1-2[illegible]80-130[illegible]116[illegible]119[illegible] 3

[illegible]**110**[illegible] **-** [illegible] [illegible] 110[illegible] [illegible] [illegible]110[illegible] [illegible] [illegible]

[illegible]**2025**[illegible] 5000[illegible]25[illegible] [illegible]F2z 110 Max[illegible]Mz 110[illegible]Qz1 MIX[illegible]6000[illegible]MMAX[illegible]Dz 110P[illegible]

[illegible]**110**[illegible] **-** [illegible] [illegible] [illegible] [illegible]

[illegible]**110[illegible]90[illegible]60[illegible]50? -** [illegible] 110[illegible]90[illegible]60[illegible]50[illegible] [illegible]

[illegible]**110**[illegible] **-** [illegible] [illegible]110[illegible] [illegible]1

[illegible]**ftp**[illegible]**? -** [illegible] [illegible]FTP[illegible] 1.[illegible]FTP[illegible] 2.[illegible]Windows[illegible]

[illegible]**110[illegible]119[illegible]120**[illegible] **-** [illegible] [illegible]110[illegible]119[illegible]120[illegible] [illegible] [illegible]999[illegible]122[illegible]12395[illegible]95110[illegible]12308[illegible]

[illegible] **110** [illegible] **-** [illegible] 110 [illegible] [illegible]110[illegible]

[illegible] [illegible]
1[illegible] [illegible]

[illegible] **-** [illegible] [illegible] [illegible] [illegible]1[illegible]70-190 1[illegible]11[illegible]80-160[illegible]128[illegible]130[illegible] 1-2[illegible]80-130[illegible]116[illegible]119[illegible] 3